



ANOVA

Connecting the industrial world - for better.

ANOVA

GO

NEW INSTALL GUIDE

ABSTRACT:


This document provides users a quick guide on how to do an install using Anova GO.

ANOVA SUPPORT

NORTH AMERICA: +1 844-493-7762



7AM CST to 5PM CST

EMAIL:
support@anova.com




1. Begin by logging in using your email address and password.


2. From the main menu, click on the "Rocket" button to make a New Deployment.




3. You can locate the device either by entering its serial number manually or by scanning the QR code using your phone's camera. Once located, select the appropriate unit.

4. Select the site where the device will be installed. If the site does not yet exist, tap "New Site" and enter the required location details. Providing accurate information will help ensure the site is easy to identify later. Once the site is selected, tap "Next".






5. You will now see a list of tanks associated with the selected location. If you need to add a new tank, tap **"Add Tank"** and complete all required fields. After entering the tank information, tap **"Next"**. You will now see a list of tanks associated with the selected location. If you need to add a new tank, tap **"Add Tank"** and complete all required fields. After entering the tank information, tap **"Next"**.




6. Select the channels you will be using—either one or two. If two channels are used, both Channel A and B must be configured.

To edit a channel, tap the pencil icon and assign the appropriate tank and sensor. Once configuration is complete, tap **"Next"**.



7. You will be prompted to activate the device. Tap **"Continue"** when ready. The system will automatically connect and activate the unit. Please wait for the activation to complete successfully.



8. Once the activation is successful, tap **"Next"** to finalize the installation.